

Next Pole Bracket Card Terminal


E-no: 2701288

Assembly instructions

Included fasteners:


4 pcs screw MFX PH	M4x25
4 pcs locknut	M4
4 pcs washer	M4

All electrical installation work must be carried out by an authorized installer and meet the installation requirements in the country of use.



Mounting the bracket to Next Pole

Use the screws included with Next Pole to fasten the bracket. The bracket only fits at the front and the service hatch is at the rear of Next Pole.



Mount the card terminal's mounting plate

Disassemble the top of Next Pole for better visual access during installation.

Depending on the type of mounting plate for the card terminal, the included spacer plate may be required. It reduces the cable opening in Next Pole and provides a flat surface for mounting the card terminal's plate.

Mount the plate, with or without the spacer plate, according to the manufacturer's instructions using the included M4x25 screws.


Install the card terminal

Install the card terminal according to the manufacturer's instructions.

In some cases, longer screws may be required, as the mounting plate adds 4 mm and the spacer plate approximately 3 mm. These screws are not included.

Mount the top cover and install the Next Pole cover plate (ordered separately E-no 2700660).

Mount the associated equipment onto the DIN equipment bracket (ordered separately E-no 2700661).



Next Pole Montageplåt Kortläsare

E-nr: 2701288

Monteringsanvisning


Medföljande fästelement:

4 st Skruv M4x25 MFX PH

4 st Låsmutter M4


4 st Bricka M4

Allt elinstallationsarbete måste utföras av en auktoriserad installatör och uppfylla installationskraven i användningslandet.



Montera montageplåten på Next Pole

Använd de skruvar som sitter på Next Pole till monteringen av montageplåt Kortläsare. Montageplåten kan endast monteras på Next Poles framsida. Serviceluckan sitter på dess baksida.



Montera kortläsarens fästplatta

Demontera taket på Next Pole för bättre visuell åtkomst under monteringen.

Beroende på typ av fästplatta till kortläsaren kan den medföljande distansplattan behövas. Den minskar Next Poles kabelgenomgång och kortläsarens fästplatta får ett jämt plan att monteras mot.

Montera fästplattan med eller utan distansplatta enligt tillverkarens instruktioner med de medföljande M4x25 skruvarna.

Montera Kortläsare

Montera kortläsaren enligt instruktioner från tillverkaren. Ibland kan längre skruvar behövas då Montageplåten bygger 4 mm och distansplattan bygger ca 3 mm. Dessa medföljer ej.

Återmontera taket och montera Next Pole täcklucka (beställs separat på E-nr 2700660).

Montera tillhörande utrustning på Montagebox DIN (beställs separat på E-nr 2700661)

